



JP1 AND JP2 CONFIGURE FOR GPS MODEL  
 JP4 = OUT FOR PROGRAMMING  
 JP4 = IN FOR NORMAL OPERATION  
 T = IN FOR TRIPMATE, OUT FOR OTHERS  
 N = OUT FOR TRIPMATE, IN FOR OTHERS

Co:	TAPR, INC.
Title:	PIC-E
Board:	PIC-E
Author:	STEVE BIBLE, N7HPR
Date:	10/13/98
Revision:	1A
Size:	A
Sheet	1 of 1